

ROCCO

Product Unpacking Instructions

The packaging contains :

- i. (1) ATA approved flight case;
- ii. (1) Power cord;
- iii. (2) Speaker grilles;
- iv. (1) Hardened glass;
- v. (2) Accessory boxes;
- vi. (1) Package containing the owner's manual.

One accessory box contains :

- i. (4) Threaded spikes;
- ii. (4) Threaded spikes locking nuts.

The other accessory box contains :

- i. (9) Sorbothane bumpers.

WARNING: The Rocco's module and its packaging are big and heavy. Any operations that ask for moving, lifting or tilting will require the assistance of a second person. Attempting to do it alone could be hazardous, create injuries or permanent damage to the loudspeaker.

1. Cut and remove the tie wrap which securely holds the four (4) latches of the subwoofer;
2. Lift each of the latch's handles, then twist counterclockwise 180 degrees and pull to release;
3. Completely open and remove the upper shell of the flight case;
4. Remove the power cord located inside the port;
5. Place the hands under the central section of the cabinet. Lift the section and carefully lay it on the base of the flight case;
6. Turn the subwoofer over on one speaker side;
7. Assemble the four (4) spike locking nuts with the four (4) threaded spikes. Leave approximately half an inch between the tip end and the nut;
8. Move the subwoofer back on its spikes;
9. Connect the power cord to the subwoofer and to the wall outlet;
10. Connect the signal output to the selected Rocco input panel. Adjust the subwoofer position and the control for the best result. (See the owner's manual for detailed information.) This adjustment should be done without the grilles and glass;
11. Place the nine (9) sorbothane bumpers on the Rocco active subwoofer. Make a 3 X 3 array. Remove the hardened glass at the bottom of the flight case and carefully place it on the sorbothane bumpers;
12. Attach the grilles on each side;
13. Place unused accessories inside the flight case and store it away.

ROCCO

Product Packing Instructions

The complete packaging should include:

- i. (1) ATA approved flight case;
- ii. (2) Accessory boxes;
- iii. (1) Package containing the owner's manual.

One accessory box contains :

- i. (4) Threaded spikes;
- ii. (4) Threaded spikes locking nuts.

The other accessory box contains :

- i. (9) Sorbothane bumpers.

WARNING: The Rocco's module and its packaging are big and heavy. Any operations that ask for moving, lifting or tilting will require the assistance of a second person. Attempting to do it alone could be hazardous, create injuries or permanent damage to the loudspeaker.

1. Turn off all audio and video equipment. Remove the power cord and all the interconnects signal input cable from the Rocco active subwoofer input. The power cord can be stored inside the port;
2. Temporarily remove the subwoofer grilles;
3. Remove the glass and place it at the bottom of the flight case;
4. Remove the nine (9) sorbothane bumpers and store them in one accessory box;
5. Turn the subwoofer over on one speaker side. You should do it on a soft surface (a clean carpet or a big cotton cloth);
6. Remove the four (4) spike locking nuts and the four (4) threaded spikes. Store them inside the other accessory box;
7. Place the subwoofer back on its upright position;
8. Place the hands under the central section of the cabinet. Lift the section and carefully lay it on the base of the flight case;
9. Reinstall the two (2) speaker grilles;
10. Store the accessory boxes and the owner's manual inside the provided space;
11. Carefully install the upper shell of the flight case by matching the two black pop rivets;
12. Secure the cover in place by closing the four (4) latches. *Locking the latches with tie wraps is highly recommended;*
13. The Rocco active subwoofer is ready to be labeled and shipped.